the Delta User Manual

Notice for Use
Thank you for choosing Joyetech! To ensure safe and proper usage, please read this manual carefully. If you require any additional information or have any questions regarding this product or its use, please consult your local Joyetech retailer, or visit our website at www.joyetech.com.

Product Introduction
The 6ml large volume and three adjustments of air inflow highlight the Delta. Replaceable mouthpiece and atomizer head are available on Delta due to its new atomizer head, the C3 atomizer head. The C3 atomizer head boasts triple coils with the resistance of 1.4ohm, which ensures the large amount of vapor under high voltage(4.0V-6.0V) and high wattage(11.5W-26.0W), being compatible with most high-wattage batteries in the market. Not only that, but the Delta features three glass liquid-windows, making the liquid volume more open-and-shut. Regarding to its material, the all stainless steel construction creates an environmental puff.

Standard Configuration
1× Delta Mouthpiece
1×Delta Atomizer Tube
2× C3 atomizer head
1× Delta Atomizer Base

Features of Delta spare parts
Size: 23mm*87.8mm(including mouthpiece and base)
Delta Mouthpiece: pluggable, plastic, replaceable
C3 Atomizer Head: rotatory, replaceable, triple coils at bottom
Delta Atomizer Tube: all stainless steel construction
Delta Atomizer Base: all stainless steel construction

How to Assemble
1. Screw the C3 atomizer head onto the Delta atomizer base along the clockwise.
2. Screw the base onto the Delta atomizer tube along the counterclockwise.
3. Plug on the replaceable mouthpiece.



Liquid filling
Unscrew the atomizer tube from the Delta base.
Simply refill e-Liquid into the hole from the bottom along the inwall of Delta atomizer tube.

How to Use
360° Adjustment of air inflow: Rotating the ring on the atomizer base clockwise or counterclockwise to adjust the inlet valve. There are three slots on the atomizer base, and they respectively represent the different air inflow, from small to large.

Several key points:
• Please do not refill the e-liquid into the small hole in the center of the atomizer tube.
• When you unscrew the Delta base from the atomizer tube, the atomizer head may follow to become loose, so do remember to tighten it before re-screw the atomizer base on the tube.
• Please do take ten puffs under 4.0 Voltage in first use is case that the new atomizer head get damage under high voltage mode.

Precautions
1. Only have your Delta repaired by Joyetech. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
2. Do not leave the Delta in high temperatures or damp conditions, as this may damage the device. The appropriate operation temperature is within 0℃ to45℃ while charging and-10℃ to 60℃ while in use.
3. Do not attempt to combine the Delta with parts from other brands of e-cigarettes. If it isdamaged in this way, Joyetech will not take responsibility and your warranty will be void.

Warranty terms
Please consult your Joyetech product warranty card. We are not responsible for anydamage caused by user error. Our warranty is not valid for products purchased fromthird party vendors.

Joyetech agrees to provide repair under warranty pursuant to the following terms and conditions:

1. This warranty provides repair free of charge for defective Joyetech brand merchandise. Warranty period is 90days from date of purchase by the end user.

2. This warranty may be void as a result of any of the following conditions:
* Customer does not provide warranty card and original receipt of purchase.
* Merchandise failure or damage is caused due to improper use or unauthorized repair.
* Merchandise failure or damage as a result of excessive force such as dropping.
* Merchandise failure or damage as a result of usage outside of recommended operating conditions (seeprecautions in usage manual).
* Merchandise failure or damage caused by improper use of water or other liquid (see usage manual foroperating instructions).
* Merchandise failure or damage due to usage with non-Joyetech components (charger, battery, and power cable).

3. This warranty does not cover personal items or consumable goods and attachments, including but not limitedto: mouthpiece, cartridge, atomizer head, lanyard, and leather sheath.

4. This warranty does not cover any non-Joyetech brand products. This warranty is only valid for eligible Joyetechbrand products during the warranty period of 90 days after date of purchase as indicated on proof of purchase.

Joyetech reserves the right of final decision in all warranty cases.
Joyetech may interpret and revise thecontent of this warranty terms.

MADE IN CHINA

Joyetech (Shenzhen) Electronics Co., Ltd.
Email:info@joyetech.com